



---

## **Sterilizing Procedures for Bur Blocks, Code Rings, Set-up Trays, Instrument Mats, Mirrors, Steri-Cassettes and Steri-Cages**

These items can be processed through an ultrasonic cleaner or thermal disinfectant, then dried, wrapped, and processed through a Chemiclave or dental autoclave (*typically operating at 250° or 270°F*). The code rings can also be processed through dry heat.